

Fluoride test

## Test preparation:

- 1 Fill both tubes up to the mark with the test water.
- 2 Put the contents of the F<sup>-</sup>R1 ampule into one of the two tubes (test), close with the screw top lid and mix.
- 3 Add 2 small level measuring spoon of F<sup>-</sup> R2 to the test, close with the screw top lid and dissolve by shaking.



Measure after exactly 8 minutes reaction time.

## Measuring with AQUA-CHECK:


- 1 Reference measurement.
- 2 Test measurement.





You will find important information on your measurement value at www.aqua-check.de. Please observe the safety notes for handling chemicals (see rear).





Fluoride test

## F-R1 (fluoride test)

S2: Keep out of the reach of children. S25: Avoid contact with eyes.

## F- R2 (fluoride test)

S2: Keep out of the reach of children.

Take packaging with product residues to hazardous or special waste disposal.