

Maintenance:

Replace the battery when the display becomes weak. Please do not dispose of old electronic devices and used batteries in household waste. To protect the environment, take them to your retail store or to nearest civic amenity site to be disposed of according to national or local regulations.

Do not expose the instrument to extreme temperatures, vibration or shock.

Clean it with a soft damp cloth. Do not use solvents or scouring agents.

Please do not try to repair the unit. Contract the original point of purchase. Please change the battery complaining. No guarantee if the instrument is handled or opened improperly.

Attention:

Please do not dispose of old electronic devices and empty batteries in household waste. To protect the environment, take them to your retail store or to appropriate collection sites according to national or local regulations.



TripleTime

Digital Triple Timer

Please read operating instructions first!
Do not throw operating instructions away!

Features:

- 3 count down timer, simultaneous operation possible
- Count-up timer
- Clock
- Hours/minutes/seconds display
- Up to 19 hrs., 59 min. and 59 sec.
- With magnet for fixing
- Battery 1,5 V AAA included

Use:

Open the battery compartment and insert the battery, polarity as illustrated.

The unit is now ready to use.

Press MODE button to select between TIMER 1, TIMER 2, TIMER 3, CLOCK & COUNT UP.

Count Down Timer:

Press MODE Button to select between TIMER 1, TIMER 2, TIMER 3.

Press and hold MEMORY button. The "MEM" icon appears on the display and the indication is flashing.

Use HR button to set hours, MIN button to set minutes and SEC button to set seconds. Press MEMORY button to confirm.

Press START/STOP button to start the countdown.

Use START/STOP button to stop and restart the countdown.

To clear the countdown reading use CLEAR button.

When the countdown reaches 00.00.00, an alarm will sound for 1 minute and an upward flash appears on the display. Now the timer will start to count up over time until it is stopped using START/STOP button.

For simultaneous operation of all three timers set the desired time for TIMER 1, TIMER 2, TIMER 3.

Press MODE and START/STOP button at the same time to stop and restart the countdown of all timers.

Time:

Press MODE button to select CLOCK & COUNT UP.

Press and hold MEMORY button. The indication is flashing.

Use HR button to set hours and MIN button to set minutes.

Use 12/24 button to select 12 or 24 hours time system.

Press MEMORY button to confirm.

Stopwatch:

Press MODE button to select CLOCK & COUNT UP.

Press START/STOP button to start the count up.

Use START/STOP button to stop and restart.

To clear the reading use CLEAR button.