


# TH

# TH test

For fresh and salt water

- 1 Fill the tube up to the mark with the test water.
- 2 Slowly allow the indicator solution to drop in with continual swivelling.
- 3 Count the drops until the colour change from pink to blue is complete.



## Calculation:

Indicator drops x 0.5 = TH (°dH)

A drop of indicator solution equals 0.5°dH.

## Evaluation:

- If the determined value is 5°dH or more, the total hardness is sufficient.
- If the value is below 5°dH the total hardness is too low.



You will find important information on your measurement value at [www.aqua-check.de](http://www.aqua-check.de).  
Please observe the safety notes for handling chemicals (see rear).



***Irritant***

## TH test

R36: Irritating to eyes.

S2: Keep out of the reach of children.

S26: In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.

**Take packaging with product residues to hazardous or special waste disposal.**

**Söll GmbH** • Fuhrmannstraße 6 • D-95030 Hof • [www.soelltec.de](http://www.soelltec.de) • Tel. +49(0)92 81/72 85-0  
Söll hotline: 0 700/92 77 37 55 (14 cents/minute from a German landline)