

Cu²⁺

Copper test


For fresh and salt water

Test preparation:


- 1 Fill both tubes up to the mark with the test water.



- 2 Add **1 big** level measuring spoon of **Cu²⁺ R1** to one of the two tubes (test), close with the screw top lid and dissolve by shaking.




- 3 Add the contents of the **Cu²⁺ R2** ampule to the test, close with screw top lid and mix. Leave standing for 5 minutes.




Measuring with AQUA-CHECK:

- 1 Reference measurement.
- 2 Test measurement.

 With concentrations greater than 3mg/L copper you must expect low quality results.



 You will find important information on your measurement value at www.aqua-check.de. Please observe the safety notes for handling chemicals (see rear).

Cu²⁺

Copper test

Version 1.0 • 03/2012

Cu²⁺ R1 (Copper test)

S2: Keep out of the reach of children.

S46: If swallowed, seek medical advice immediately and show this container or label.

Cu²⁺ R2 (Copper Test)

S2: Keep out of the reach of children.

S46: If swallowed, seek medical advice immediately and show this container or label.

Take packaging with product residues to hazardous or special waste disposal.

Söll GmbH • Fuhrmannstraße 6 • D-95030 Hof • www.soelltec.de • Tel. +49(0)92 81/72 85-0
Söll hotline: 0 700/92 77 37 55 (14 cents/minute from a German landline)

CLHM2-15995