



Oxygen test

Version 2.0 • 11/2014



Harmful

O_2 R1

R48/20/22: Harmful: danger of serious damage to health by prolonged exposure through inhalation and if swallowed.

R52/53: Harmful to aquatic organisms, may cause long-term adverse effects in the aquatic environment.

S2: Keep out of the reach of children.

S46: If swallowed, seek medical advice immediately and show this container or label.

May cause eye or skin irritation with susceptible persons.

Contains Manganese sulfate monohydrate



Corrosive

O_2 R2

R35: Causes severe burns.

S1/2: Keep locked up and out of the reach of children.

S26: In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.

S37/39: Wear suitable gloves and eye/face protection.

S45: In case of accident or if you feel unwell, seek medical advice immediately (show the label where possible).

Contains Sodium hydroxide



Irritant

O_2 R3

R36: Irritating to eyes.

S2: Keep out of the reach of children.

S26: In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.

S46: If swallowed, seek medical advice immediately and show this container or label.

Take packaging with product residues to hazardous or special waste disposal.

Söll GmbH • Fuhrmannstraße 6 • D-95030 Hof • www.soelltec.de • info@soelltec.de

O₂

Oxygen test

For fresh and salt water

Test preparation:

1 Fill both tubes up to the mark with the test water.

2 Add **8 drops of O₂ R1** into one of the two tubes (test-tube), close with the screw top lid and sway gently.

⚠ Do not shake!

3 Add **2 drops of O₂ R2** into the test-tube and close with the screw top lid.

Mix gently for 60 seconds.

⚠ Do not shake!

Allow the liquid to stand for 1 minute.

4 Add **10 drops O₂ R3** into the test-tube and close with the screw top lid.






Mix gently for 30 seconds.

⚠ Do not shake!

Allow the liquid to stand for 2,5 minutes.

5 Reference measurement during the waiting time of 2,5 minutes.

6 Test measurement exactly after the waiting time of 2,5 minutes.



⚠ Immediate